













## SPARE PARTS LIST

01. PUNCHBALL	02. LEATHER FOR PUNCHBALL	03. RUBBER CONE
		
04. KICKER BALL	05. KICKER PROTECTOR	06. BOXER PROTECTOR (Circle or Rectangular)
		
07. SOLENOID 12V	08. SOLENOID 24V (Small or Big)	09. TRANSFORMER (12V, 24V, Multiplayer, ARM)
		
10. PILLOW (Rubber Type or Cushion Type)	11. BLADDER - BLACK	12. BLADDER - ORANGE
		
13. START BUTTON (BIG or 40mm)	14. BUTTON MAN / WOMAN	15. BUTTON ON / OFF
		


<b>16. BIG DOOR</b>	<b>17. SMALL DOOR (Cash Box)</b>	<b>18. COIN MECH COMESTERO</b>
		
<b>19. CREDIT DISPLAY</b>	<b>20. HIGHSOCRE DISPLAY</b>	<b>21. SCORE DISPALY</b>
		
<b>22. COMPLETE MECHANISM (Boxer, Kicker)</b>	<b>23. SLEEVE FOR SPRING</b>	<b>24. SPRING FOR SLEEVE (Left or Right)</b>
		
<b>25. SPRING FOR MECHANISM (Boxer or Kicker)</b>	<b>26. SCREW WITH SLEEVE (Boxer or Kicker)</b>	<b>27. KICKER RUBBER FENDER WITH SLEEVES (Srews: 10' or 12')</b>
		
<b>28. SILENT BLOCK – SMALL (Mechanism)</b>	<b>29. SILENT BLOCK (For Punchball)</b>	<b>30. RUBBER UNDER MECHANISM (Kicker)</b>
		

<b>31. RUBBER SLEEVE FOR KICKER RUBBER FENDER</b>	<b>32. ELECTRIC WIRE RUBBER</b>	<b>33. RUBBER WITH TWO SCREWS (For Kicker, behind mechanism)</b>
		
<b>34. HAMMER FOR MECHANISM</b>	<b>35. TIES FOR MECHANISM (Metal "S", Metal "M", "U" Type, "H" Type)</b>	<b>36. LED LIGHT / HALOGEN BULB</b>
		
<b>37. COIN MECH CABLE</b>	<b>38. CABLE (Mainboard-Display – 50")</b>	<b>39. POWER SUPPLY CABLE</b>
		
<b>40. POWER SUPPLY SOCKET</b>	<b>41. DOOR LOCK REVISION</b>	<b>42. DOOR LOCK</b>
		
<b>43. ARM FOR KICKER (Circle, Quadratic, Teflon 32 or 35mm)</b>	<b>44. CLIP FOR KICKER ARM (Circle)</b>	<b>45. MECHANICAL COUNTER</b>
		

**46. BOXER / KICKER SENSORE**



**47. SENSORE BOXER (One Assembly Hole)**




**48. SENSORE KICKER (Two Assembly Hole or One Assembly Hole with Bent Badge)**



**49. FRONT PLEXI BOXER (De Luxe, Shield Type)**



**50. FRONT PLEXI KICKER (Circle)**



**51. PLEXI BOXER "BELT"**



**52. PLEXI BOXER "BUTTONS"**



**53. PLEXI KICKER "BUTTONS"**



**54. SPEAKER (Big or Small)**



**55. TRANSPORT WHEEL**



**56. BOTTOM METAL - BACK**



**57. BOTTOM METAL - FRONT**



**58. MICROMOTOR .366 (Basket)**









**59. MICROSWITCH BIG**



**60. MICROSWITCH (Plate or Roll)**



<b>61. BASKETBALL SIZE 5</b>	<b>62. POWER SUPPLY ADAPTOR</b>	<b>63. SENSORE COUNTING - BOXER</b>
		
<b>64. SENSORE PENDULUM - BOXER</b>	<b>65. TEFLON CATCHER - BOXER</b>	<b>66. HAMMER SENSORE</b>
		 <p><b>13 Euro</b></p>